P6SPro Instruction

Ⅰ、APP Download

1.Scan below QR code to download APP：both Android and IOS.

2.Click main menu to enter into System Setting----click P2P in Network Setting to reveal QR code. UID QR code will be showed simultaneously if there's UID. Use APP to scan and add.

Ⅱ、Device Addition & Edit

1.**Running APP：**

   Click P6SPro icon to run APP.

2.Login：

China Telecom   9:13 AM

Phone Number/Email

Please enter password

LOGIN

register new user   Forget Password

Local Device

1.Cloud login: The data of added device is stored in cloud; any mobile phone can synchronize with it after login.

New account need to be registered if login in cloud: click【Register New Account】to register via mobile number or email address, then you can login through this account and password.

If you registered before: input account &password, click【Login】is ok.

If you forgot password: click 【 Forgot Password】to find it.

2.Local login：Data only can be saved in this mobile phone.
Click【Local Device】to login.

3.Device list pages：

China Telecom   9:13 AM

Devices

Menu

Add device

No cameras

Left ☰ menu icon : Click for more functions

please log in

Devices

Live View

Playback

Images

Videos

Settings

Login first: it reveals if open it in local mode, click and login.

Device management: click to enter into it.

Real-time preview: watching real-time preview screen.

Image management: the images shot from【Real-time preview】or 【 Remote playback 】 can be viewed or deleted.

Video management: the video from【Real-time preview】can be watched or deleted.

System settings: checking system information and Help.

Right ⊕ add icon: click to add device.

evices ⊕

Manual Add

Scan

Search

Image Add

Manually addition: input serial number to add manually.

Scanning: click and open phone-camera to scan.

LAN search: search device's serial number in LAN.

QR code from image: click to invoke mobile album, choose QR code image to recognize.

4.Add device：

← ——Return   Add Camera   Save —— 🖫

Name: PVR   Customize device's name shown on the list

UID: BZWYZN-030365-EBSYM   Series number(SN)

UserName: admin   User name

Security Code: ● ● ● ● ●   Password

According to step 3, click upper-right ⊕ , choose an appropriate way to add device.

Add IPC:

Name: input custom name.

UID: the device UID you gained.

User name and password: input the user name and password of device.

Fill in and click【Save】is ok.

After adding successfully, 【Device management】will show the device.

　【Online】and【Channel QTY】are the device status.

Click Edit button, you can check and modify device information. (If device reveal error password, it needs you to click and input right user name and password.)

Click device on this page to preview directly.

Page after adding：

☰   Devices   Add device —— ⊕

🖳 PVR
BZWYZN-030365-EBSYM   ⟩
Online   Channel: 4

Status   Channel number   Edit

5.Edit device

|		
Edit Camera		Edit page:
Name: **PVR**		Name/User name/Password: all support edit again.
UID: BZWYZN-030365-EBSYM		
UserName: **admin**	Edit the device's name, user name, password	Firmware version/ device model No.: showing the device's software version and model No.
Security Code: ••••••••		
Firmware version: 2.1.1-20170608	Device's firmware version and model number	Channel management: Add/delete the channel of device. (The device needs to support this function, If it's IP camera, then it doesn't have this function.)
Device model: PVR-2504NEJ		
Channel Management ＞		
Channel management		

# Ⅲ、 **PVR quick add IPC**

1.Open APP, click ⊕ in the upper-right to add device.



2.Device added successfully and show【Online】,click【Edit】.

3.Click【Channel management】to enter into channel editing page.

Click【+】to add cameras

Choose one way to add:

Add Equipment	
✎ Manual Add	›
⊟ Scan	›
⊕ Search	›
▦ Image Add	›

| Manual Add	
Name:	Cam4
protocol:	ZWP2P ⌄
DID:	NZWYZP-142929-BFKNL
UserName:	admin
Security Code:	

Protocol：
TUTK：TUTK P2P
ZWP2P：Zowell P2P
P6S：Zowell local IP

User name and password: input camera's user name and password

Click the upper-right 【Save】

After adding：

Channel List	
📷	Cam: 1 DID: DDYHU66ELSZUT18Y111A Status: connected
📷	Cam: 2 IP: 192.168.0.76 Status: connected
📷	Cam: 3 DID: NZWYZP-112680-JEKZK Status: connected
📷	Cam: 4 Status: idle ⊕

Device will show connected condition after adding, then you can add the next channel.
Idle condition means no camera in the channel.

Protocol explanation：

ZWP2P：Zowell's P2P protocol, UID has 19 digits, two【-】in the middle, as picture channel 1.

TUTK：TUTK's P2P protocol, UID has 20 digits, as picture channel 2.

P6S：Zowell's LAN IP protocol, type is 192.168.X.X, as picture channel 3.

Ⅳ、 **Preview& Playback**

1.Preview:

When device show【Online】condition, click it to preview directly.

	PVR	
	BZWYZN-030365-EBSYM	>
	Online Channel: 4	

Status   Channel number   Edit

Real-time preview pages：

Menu

Choose channel you can choose the channel to preview

Live View

PVR-1-High-0KB/s
PVR-2-Fluent-0KB/s
PVR-3-High-111KB/s
Cam4
Click to add channel to preview

Screen number

1   4   •   9   16

Functional zone

Three preview modes:：
1.Click device list page, will skip to【Real-time preview】to play.

2.Click【Menu】to enter into【Real-time preview】, click the upper-right
Choose channels to play.

3.Click【Menu】to enter into【Real-time preview】and click ⊕ to choose
the channel to play.

Split mode:
It support 1/4/9 image split, 16 is in developing.
Remark: when you open 8 channels and set 4 image split, so two screens wi
Divided, you can slide to switch.(Screen1 shows 1-4, screen2 shows 5-8.)

Function：

📷	Capture	🎥	Record
PTZ icon	PTZ	⊕	Zoom
Close Checked icon	Close Checked	Close All icon	Close All
Resolution icon	Resolution	Audio icon	Audio switch

2.Playback：

Choose Remote Playback in menu.

Ⅴ、**Others**

Image management：
All snapshots through 〔Real-time Preview]&[Remote Playback]

Video management：
All video through [Real-time Preview] are saved here. Remark: exterior broadcaster is required for playing.

System setting：
Check System Information and Help Information. Take [Help] for complete operation.